







ITEM NO.	PART NUMBER	QTY.
1	1. Piston	1
2	2. Seal	1
3	3. Screw	1
4	4. Sealing washer	1
5	5. Filter	1
6	6. Washer	1
7	7. Retaining body	1
8	8. Body 2-X	1
9	9. Adjustment screw	1
10	10. Bearing	1
11	11. Spring washer assembly	1
12	12. Seal holder	1
13	13. First stage piston	1
14	14. Primary spring washer assembly	1
15	15. Primary sealing washer	1
16	16. First stage retaining nut	1
17	17. First stage adjustment screw	1
18	18. First stage seal	1
19	Fill nipple with check valve	1
20	High pressure gauge	1
21	Low pressure gauge	1
22	O-ring ID 2.5x1.5 NBR70	1
23	O-ring ID 3.5x2 NBR90	1
24	O-ring ID 3x3 NBR70	2
25	O-ring ID 5x1.5 NBR90	1
26	O-ring ID 6.5x2 NBR70	1
27	O-ring ID 7x1.5 NBR70	1
28	O-ring ID 10x1.5 NBR70	3
29	O-ring ID 11x1.5 NBR70	2
30	O-ring ID 13x2 NBR90	1
31	O-ring ID 16x2.5 NBR70	1